

# Ready to

## ダブルウォールカラフェ

Double - Wall Carafe

300mL/530mL

取扱説明書

ご使用前に必ずお読みください。

お読みになったあとは大切に保管してください。

**電子レンジ用**

**×オープン・直火は使用できません**

User Manual

Please read the following information  
before use, and keep for future reference.

**For Microwave Use Only**

**Do not place in oven or over direct flame.**

**marna**

TOKYO 1872

## ご使用方法


### ●ご使用前に

ケガの恐れがありますので、ご使用前にフチや注ぎ口にヒビ、欠けがない事をご確認ください。

①ドリッパーを本体の上  
のせてドリップする。



②注ぐ際は、図のようにフタの開口部を  
本体注ぎ口に合わせて注いでください。  
※フタをしたまま電子レンジにかけられます。



※1杯分約130mL

## 安全上のご注意

### ⚠危険

- 電子レンジ以外の加熱器具は使用しないでください。
- 電子レンジでの加熱しすぎや空だきはしないでください。
- 直火では加熱しないでください。破損・やけどの原因となります。
- お子様に使用させないでください。また、乳幼児の手の届くところには置かないでください。
- 電子レンジで加熱しすぎると突然お湯が激しく沸騰し吹き出すことがあります(突沸現象)。

## お手入れ方法

- ご使用前に食器用洗剤で洗ってからお使いください。
- ご使用後はよくすすぎ、水気を切って乾燥させてください。
- たわしまたは磨き粉を使用すると傷がつき破損することがありますのでご使用はおやめください。
- 汚れがひどい場合は薄めた台所用漂白剤に浸けた後、お湯で洗い流してください。

## 使用上のご注意

- ガラスは割れるものです。取り扱いにご注意ください。
- ヒビ、欠け、強いスリ傷の入ったものは破損することがありますので、使用しないでください。
- 破損する原因となりますのでスプーン等の固いもので強い衝撃を与えないでください。
- 本品が熱いうちに急激に冷やすと破損の原因になります。
- 容量目盛は、目安としてご使用ください。
- 火のそばや高温になるところには置かないでください。
- 本来の用途以外でのご使用はおやめください。
- 万一商品に欠陥がございましたらお取り替えいたします。

## 仕様

- 品名 耐熱ガラス製器具
- 使用区分 電子レンジ用
- 耐熱温度差 120°C

材質:本体/ガラス  
フタ/ポリプロピレン  
耐熱温度:フタ/120°C  
容量:K793/300mL  
K794/530mL  
原産国:本体/中国  
フタ/日本



Dishwasher  
Safe



Microwave  
Safe

## How to Use

### ● Before Use


To avoid injury, make sure there are no cracks or chips on the rim or spout.

① For drip pourover, place the dripper on top.




② To pour, align the opening of the lid with the spout of the body, as shown in the diagram.

※When microwaving, the lid can be left on.




350mL



1 and 2 cup  
measurements

530mL



2 and 4 cup  
measurements

※Approx. 130mL per cup

## Usage Precautions

### ⚠ Danger

- Do not use with any heating device other than the microwave.
- When microwaving, do not overheat or heat the carafe while empty.
- Do not heat over an open flame. Doing so may cause damage or burns.
- Not for use by children. Keep out of reach of infants.
- Overheating in the microwave may cause water to boil over and splash violently (known as liquid bumping).

## Maintenance

- Wash the product with a dish detergent before use.
- After use, rinse thoroughly, drain all liquids, and dry.
- Do not clean with a brush or polishing agent. Doing so may scratch the product.
- For persistent stains, soak in diluted kitchen bleach and rinse with hot water.

## Precautions for Use

- The glass is breakable. Be careful when handling.
- Do not use cracked, chipped, or severely scratched carafes, as they may shatter.
- Do not subject to hard impacts with spoons or other objects, as the carafe may shatter.
- Rapid cooling while hot may cause the carafe to shatter.
- Use the volume markings as a scale.
- Do not place next to flame or in high temperature areas.
- Do not use this product outside of its intended purpose of use.

## Specifications

Materials: Body/Glass Lid/PP

Withstands temperatures up to 248°F/120°C (Body),

Endures up to 248°F/120°C (Lid)

Capacity: K793 Approx. 10.1oz/300mL

K794 Approx. 17.9oz/530mL



Dishwasher  
Safe



Microwave  
Safe

# Ready to

Double-Wall Carafe



株式会社マーナ

〒130-0005 東京都墨田区東駒形1-3-15  
03-3829-1111

**Marna Inc.**

1-3-15, Higashi-komagata, Sumida-ku,  
Tokyo 130-0005 Japan

[marna.jp](http://marna.jp)



K793X500